


LUBE PUMP ASSEMBLY

#20080



Item	Part No.	Description	Req'd
1	13735	Lubricator, Manual (w/Filter Element)	1
2	17526	Guard, Manual Lubricator	1
3	G-104-S	Screw, Cap, Soc. But. Hd. 1/4-20x5/8"L	2
4	CB-109-A	Washer, Lock, Int. Tooth, 1/4"	2
5	13736	Sleeve, Compression, 5/32" Tubing	6
6	13737	Bushing, Compression, 5/32" Tubing	7
7	13738	Junction, 4-Way, 5/32"	1
8	13739-21	Tubing, Steel, Lube Oil, 5/32x21"L	2
9	13739-28	Tubing, Steel, Lube Oil, 5/32x28"L	1
10	13739-33	Tubing, Steel, Lube Oil, 5/32x33"L	1
11	G-108	Screw, Cap, Soc. But. Hd. 1/4-20x1 1/4"L	1
12	B-101	Nut, Hex, 1/4-20	1
13	01560	Clamp, Jiffy, Double Loop, 1/8"	2
14	01559	Clamp, Jiffy, Single Loop, 1/8"	4
15	NF-503-F	Screw, S-Tap, Sl Pn Hd TPF #10-24x1/2"L	3
16	13754	Plate, Instruction, Lubricator	1
17	13753	Filter Element (Replacement)	--